


RELAY #1 NORMALLY OPEN ON PIN 1
 RELAY #1 COMMON ON PIN 2
 RELAY #1 NORMALLY CLOSED ON PIN 3
 RELAY #2 NORMALLY OPEN ON PIN 4
 RELAY #2 COMMON ON PIN 5
 RELAY #2 NORMALLY CLOSED ON PIN 6



PIN

6 NOT USED

5 COMM RTN

4 RX


3 TX

2 RTS

1 NOT USED

THE ABOVE DIAGRAM DEPICTS THE WIRING FROM THE CABLE ASSEMBLY OF THE LOAD CELL TO THE CONNECTOR FOR THE METER

PIN OUT FOR DFI INFINITY METERS



PIN OUT FOR DFI 7000 METERS

